

**MKS Type 690A Absolute and  
Type 698A Differential  
High Accuracy Pressure  
Transducers**

*Copyright © 2009 by MKS Instruments, Inc.*

*All rights reserved. No part of this work may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, or by any information storage or retrieval system, except as may be expressly permitted in writing by MKS Instruments, Inc.*

Baratron® is a registered trademark of MKS Instruments, Inc., Andover, MA

VCR® and VCO® are registered trademarks of Swagelok Company, Solon, OH

Inconel® is a registered trademark of Inco Alloys Inc., Huntington, WV

## Table of Contents

Pressure Transducer Safety Information.....	1
Symbols Used in This Instruction Manual.....	1
Symbols Found on the Unit .....	2
Safety Procedures and Precautions .....	3
Sicherheitshinweise für den Druckmeßumformer .....	5
In dieser Betriebsanleitung vorkommende Symbole .....	5
Erklärung der am Gerät angebrachten Symbole .....	6
Sicherheitsvorschriften und Vorsichtsmaßnahmen.....	7
Informations relatives à la sécurité pour le transducteur de pression .....	9
Symboles utilisés dans ce manuel d'utilisation .....	9
Symboles apparaissant sur l'unité .....	10
Mesures de sécurité et précautions .....	11
Medidas de seguridad del transductor de presión .....	13
Símbolos usados en este manual de instrucciones .....	13
Símbolos hallados en la unidad.....	14
Procedimientos y precauciones de seguridad.....	15
Chapter One: General Information .....	19
Introduction.....	19
How This Manual is Organized .....	20
Customer Support .....	20
Chapter Two: Installation .....	21
How To Unpack the Type 690A/698A Unit.....	21
Unpacking Checklist.....	21
Interface Cables .....	22
System Interface Cables.....	22
Generic Shielded Cables.....	23
Setup .....	25
Dimensions .....	25
Mounting Instructions.....	26

Chapter Three: Overview .....	29
Functional Description.....	29
Transducer Simulator.....	30
Chapter Four: Operation .....	31
General Information.....	31
How To Zero the Transducer .....	33
How To Zero the Transducer Using the Zero Pot.....	33
How To Zero The Transducer using the Zero Control .....	34
How To Properly Adjust the Zero Control .....	35
How To Perform a System Check.....	36
How To Recalibrate the Electronics Unit .....	36
How To Optimize Long Cable Operation.....	38
Chapter Five: Maintenance and Troubleshooting.....	41
General Information.....	41
Maintenance.....	41
How To Clean the Unit.....	41
Troubleshooting .....	42
Appendix A: Product Specifications.....	45
Appendix B: Model Code Explanation.....	47
Model Code.....	47
Index .....	49

## List of Figures and Tables

### ***Figures***

Figure 1: Type 690A Pressure Transducer .....	19
Figure 2: Preferred Method To Connect an Overall Metal Braided Shielded Cable .....	24
Figure 3: Alternate Method To Connect an Overall Metal Braided Shielded Cable .....	24
Figure 4: Dimensions of Type 690A and 698A Pressure Transducers.....	25

### ***Tables***

Table 1: Definition of Symbols Found on the Unit .....	2
Tabelle 2: Bedeutung der am Gerät angebrachten Symbole.....	6
Tableau 3: Définition des symboles apparaissant sur l'unité .....	10
Tabla 4: Definición de los símbolos hallados en la unidad.....	14
Table 5: System Interface Cables.....	22
Table 6: Maximum Pressures for Proper Zero Adjustment .....	32
Table 7: Troubleshooting Chart.....	43



## Pressure Transducer Safety Information

### Symbols Used in This Instruction Manual

Definitions of WARNING, CAUTION, and NOTE messages used throughout the manual.

---

#### Warning



The WARNING sign denotes a hazard to personnel. It calls attention to a procedure, practice, condition, or the like, which, if not correctly performed or adhered to, could result in injury to personnel.

---

---

#### Caution



The CAUTION sign denotes a hazard to equipment. It calls attention to an operating procedure, practice, or the like, which, if not correctly performed or adhered to, could result in damage to or destruction of all or part of the product.

---

---

#### Note



The NOTE sign denotes important information. It calls attention to a procedure, practice, condition, or the like, which is essential to highlight.

---

## Symbols Found on the Unit

The following table describes symbols that may be found on the unit.

Definition of Symbols Found on the Unit			
On (Supply) IEC 417, No.5007	Off (Supply) IEC 417, No.5008	Earth (ground) IEC 417, No.5017	Protective earth (ground) IEC 417, No.5019
Frame or chassis IEC 417, No.5020	Equipotentiality IEC 417, No.5021	Direct current IEC 417, No.5031	Alternating current IEC 417, No.5032
Both direct and alternating current IEC 417, No.5033-a	Class II equipment IEC 417, No.5172-a	Three phase alternating current IEC 617-2 No.020206	
Caution, refer to accompanying documents ISO 3864, No.B.3.1	Caution, risk of electric shock ISO 3864, No.B.3.6	Caution, hot surface IEC 417, No.5041	

Table 1: Definition of Symbols Found on the Unit

## **Safety Procedures and Precautions**

**Observe the following general safety precautions during all phases of operation of this instrument. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of intended use of the instrument and may impair the protection provided by the equipment. MKS Instruments, Inc. assumes no liability for the customer's failure to comply with these requirements.**

### **DO NOT SUBSTITUTE PARTS OR MODIFY INSTRUMENT**

Do not install substitute parts or perform any unauthorized modification to the instrument. Return the instrument to an MKS Calibration and Service Center for service and repair to ensure that all safety features are maintained.

### **SERVICE BY QUALIFIED PERSONNEL ONLY**

Operating personnel must not attempt component replacement and internal adjustments. Any service must be made by qualified service personnel only.

### **USE CAUTION WHEN OPERATING WITH HAZARDOUS MATERIALS**

If hazardous materials are used, users must take responsibility to observe the proper safety precautions, completely purge the instrument when necessary, and ensure that the material used is compatible with the materials in this product, including any sealing materials.

### **PURGE THE INSTRUMENT**

After installing the unit, or before removing it from a system, purge the unit completely with a clean, dry gas to eliminate all traces of the previously used flow material.

### **USE PROPER PROCEDURES WHEN PURGING**

This instrument must be purged under a ventilation hood, and gloves must be worn for protection.

### **DO NOT OPERATE IN AN EXPLOSIVE ENVIRONMENT**

To avoid explosion, do not operate this product in an explosive environment unless it has been specifically certified for such operation.

### **USE PROPER FITTINGS AND TIGHTENING PROCEDURES**

All instrument fittings must be consistent with instrument specifications, and compatible with the intended use of the instrument. Assemble and tighten fittings according to manufacturer's directions.

### **CHECK FOR LEAK-TIGHT FITTINGS**

Carefully check all vacuum component connections to ensure leak-tight installation.

### **OPERATE AT SAFE INLET PRESSURES**

Never operate at pressures higher than the rated maximum pressure (refer to the product specifications for the maximum allowable pressure).

### **INSTALL A SUITABLE BURST DISC**

When operating from a pressurized gas source, install a suitable burst disc in the vacuum system to prevent system explosion should the system pressure rise.

### **KEEP THE UNIT FREE OF CONTAMINANTS**

Do not allow contaminants to enter the unit before or during use. Contamination such as dust, dirt, lint, glass chips, and metal chips may permanently damage the unit or contaminate the process.

### **ALLOW PROPER WARM UP TIME FOR TEMPERATURE-CONTROLLED UNITS**

Temperature-controlled units will only meet specifications when sufficient time is allowed for the unit to meet, and stabilize at, the designed operating temperature. Do not zero or calibrate the unit until the warm up is complete.

## Sicherheitshinweise für den Druckmeßumformer

### In dieser Betriebsanleitung vorkommende Symbole

Bedeutung der mit WARNUNG!, VORSICHT! und HINWEIS gekennzeichneten Absätze in dieser Betriebsanleitung.

---

#### Warnung!



**Das Symbol WARNUNG! weist auf eine Gefahr für das Bedienpersonal hin. Es macht auf einen Arbeitsablauf, eine Arbeitsweise, einen Zustand oder eine sonstige Gegebenheit aufmerksam, deren unsachgemäße Ausführung bzw. ungenügende Berücksichtigung zu Verletzungen führen kann.**

---

---

#### Vorsicht!



**Das Symbol VORSICHT! weist auf eine Gefahr für das Gerät hin. Es macht auf einen Bedienungsablauf, eine Arbeitsweise oder eine sonstige Gegebenheit aufmerksam, deren unsachgemäße Ausführung bzw. ungenügende Berücksichtigung zu einer Beschädigung oder Zerstörung des Gerätes oder von Teilen des Gerätes führen kann.**

---

---

#### Hinweis



**Das Symbol HINWEIS macht auf wichtige Informationen bezüglich eines Arbeitsablaufs, einer Arbeitsweise, eines Zustands oder einer sonstige Gegebenheit aufmerksam.**

---

## Erklärung der am Gerät angebrachten Symbole

Nachstehender Tabelle sind die Bedeutungen der Symbole zu entnehmen, die am Gerät angebracht sein können.

<b>Bedeutung der am Gerät angebrachten Symbole</b>			
Ein (Energie) IEC 417, No.5007	Aus (Energie) IEC 417, No.5008	Erdanschluß IEC 417, No.5017	Schutzleiteranschluß IEC 417, No.5019
Masseanschluß IEC 417, No.5020	Aquipotential-anschluß IEC 417, No.5021	Gleichstrom IEC 417, No.5031	Wechselstrom IEC 417, No.5032
Gleich- oder Wechselstrom IEC 417, No.5033-a	Durchgängige doppelte oder verstärkte Isolierung IEC 417, No.5172-a	Dreileiter- Wechselstrom (Drehstrom) IEC 617-2, No.020206	
Warnung vor einer Gefahrenstelle (Achtung, Dokumentation beachten) ISO 3864, No.B.3.1	Warnung vor gefährlicher elektrischer Spannung ISO 3864, No.B.3.6	Höhere Temperatur an leicht zugänglichen Teilen IEC 417, No.5041	

Tabelle 2: Bedeutung der am Gerät angebrachten Symbole

## **Sicherheitsvorschriften und Vorsichtsmaßnahmen**

**Folgende allgemeine Sicherheitsvorschriften sind während allen Betriebsphasen dieses Gerätes zu befolgen. Eine Mißachtung der Sicherheitsvorschriften und sonstiger Warnhinweise in dieser Betriebsanleitung verletzt die für dieses Gerät und seine Bedienung geltenden Sicherheitsstandards, und kann die Schutzvorrichtungen an diesem Gerät wirkungslos machen. MKS Instruments, Inc. haftet nicht für Mißachtung dieser Sicherheitsvorschriften seitens des Kunden.**

### **Niemals Teile austauschen oder Änderungen am Gerät vornehmen!**

Ersetzen Sie keine Teile mit baugleichen oder ähnlichen Teilen, und nehmen Sie keine eigenmächtigen Änderungen am Gerät vor. Schicken Sie das Gerät zwecks Wartung und Reparatur an den MKS-Kalibrierungs- und -Kundendienst ein. Nur so wird sichergestellt, daß alle Schutzvorrichtungen voll funktionsfähig bleiben.

### **Wartung nur durch qualifizierte Fachleute!**

Das Auswechseln von Komponenten und das Vornehmen von internen Einstellungen darf nur von qualifizierten Fachleuten durchgeführt werden, niemals vom Bedienpersonal.

### **Vorsicht beim Arbeiten mit gefährlichen Stoffen!**

Wenn gefährliche Stoffe verwendet werden, muß der Bediener die entsprechenden Sicherheitsvorschriften genauestens einhalten, das Gerät, falls erforderlich, vollständig spülen, sowie sicherstellen, daß der Gefahrstoff die am Gerät verwendeten Materialien, insbesondere Dichtungen, nicht angreift.

### **Spülen des Gerätes mit Gas!**

Nach dem Installieren oder vor dem Ausbau aus einem System muß das Gerät unter Einsatz eines reinen Trockengases vollständig gespült werden, um alle Rückstände des Vorgängermediums zu entfernen.

### **Anweisungen zum Spülen des Gerätes**

Das Gerät darf nur unter einer Ablufthaube gespült werden. Schutzhandschuhe sind zu tragen.

### **Gerät nicht zusammen mit explosiven Stoffen, Gasen oder Dämpfen benutzen!**

Um der Gefahr einer Explosion vorzubeugen, darf dieses Gerät niemals zusammen mit (oder in der Nähe von) explosiven Stoffen aller Art eingesetzt werden, sofern es nicht ausdrücklich für diesen Zweck zugelassen ist.

### **Anweisungen zum Installieren der Armaturen!**

Alle Anschlußstücke und Armaturenteile müssen mit der Gerätespezifikation übereinstimmen, und mit dem geplanten Einsatz des Gerätes kompatibel sein. Der Einbau, insbesondere das Anziehen und Abdichten, muß gemäß den Anweisungen des Herstellers vorgenommen werden.

### **Verbindungen auf Undichtigkeiten prüfen!**

Überprüfen Sie sorgfältig alle Verbindungen der Vakuumkomponenten auf undichte Stellen.

### **Gerät nur unter zulässigen Anschlußdrücken betreiben!**

Betreiben Sie das Gerät niemals unter Drücken, die den maximal zulässigen Druck (siehe Produktspezifikationen) übersteigen.

### **Geeignete Berstscheibe installieren!**

Wenn mit einer unter Druck stehenden Gasquelle gearbeitet wird, sollte eine geeignete Berstscheibe in das Vakumsystem installiert werden, um eine Explosionsgefahr aufgrund von steigendem Systemdruck zu vermeiden.

### **Verunreinigungen im Gerät vermeiden!**

Stellen Sie sicher, daß Verunreinigungen jeglicher Art weder vor dem Einsatz noch während des Betriebs in das Instrumenteninnere gelangen können. Staub- und Schmutzpartikel, Glassplitter oder Metallspäne können das Gerät dauerhaft beschädigen oder Prozeß und Meßwerte verfälschen.

### **Bei Geräten mit Temperaturkontrolle korrekte Anwärmzeit einhalten!**

Temperaturkontrollierte Geräte arbeiten nur dann gemäß ihrer Spezifikation, wenn genügend Zeit zum Erreichen und Stabilisieren der Betriebstemperatur eingeräumt wird. Kalibrierungen und Nulleinstellungen sollten daher nur nach Abschluß des Anwärmvorgangs durchgeführt werden.

## Informations relatives à la sécurité pour le transducteur de pression

### Symboles utilisés dans ce manuel d'utilisation

Définitions des indications AVERTISSEMENT, ATTENTION, et REMARQUE utilisées dans ce manuel.

#### Avertissement



L'indication AVERTISSEMENT signale un danger pour le personnel. Elle attire l'attention sur une procédure, une pratique, une condition, ou toute autre situation présentant un risque d'accident pour le personnel, en cas d'exécution incorrecte ou de non respect des consignes.

#### Attention



L'indication ATTENTION signale un danger pour l'appareil. Elle attire l'attention sur une procédure d'exploitation, une pratique, ou toute autre situation, présentant un risque d'endommagement ou de destruction d'une partie ou de la totalité de l'appareil, en cas d'exécution incorrecte ou de non respect des consignes.

#### Remarque



L'indication REMARQUE signale une information importante. Elle attire l'attention sur une procédure, une pratique, une condition, ou toute autre situation, présentant un intérêt particulier.

## **Symboles apparaissant sur l'unité**

Le tableau suivant décrit les symboles pouvant apparaître sur l'unité.

<b>Définition des symboles apparaissant sur l'unité</b>			
 Marche (sous tension) IEC 417, No.5007	○ Arrêt (hors tension) IEC 417, No.5008	⊥ Terre (masse) IEC 417, No.5017	⊕ Terre de protection (masse) IEC 417, No.5019
∟ Masse IEC 417, No.5020	▽ Equipotentialité IEC 417, No.5021	— Courant continu IEC 417, No.5031	~ Courant alternatif IEC 417, No.5032
∽ Courant continu et alternatif IEC 417, No.5033-a	□ Matériel de classe II IEC 417, No.5172-a	3~ Courant alternatif triphasé IEC 617-2, No.020206	
 Attention : se reporter à la documentation ISO 3864, No.B.3.1	 Attention : risque de choc électrique ISO 3864, No.B.3.6	 Attention : surface brûlante IEC 417, No.5041	

Tableau 3: Définition des symboles apparaissant sur l'unité

## **Mesures de sécurité et précautions**

**Prendre les précautions générales de sécurité suivantes pendant toutes les phases d'exploitation de cet appareil. Le non respect des ces précautions ou des avertissements contenus dans ce manuel constitue une violation des normes de sécurité relatives à l'utilisation de l'appareil et peut diminuer la protection fournie par l'appareil. MKS Instruments, Inc. n'assume aucune responsabilité concernant le non respect des consignes par les clients.**

### **PAS DE SUBSTITUTION DE PIÈCES OU DE MODIFICATION DE L'APPAREIL**

Ne pas installer des pièces de substitution ou effectuer des modifications non autorisées sur l'appareil. Renvoyer l'appareil à un centre de service et de calibrage MKS pour tout dépannage ou réparation afin de garantir le l'intégrité des dispositifs de sécurité.

### **DÉPANNAGE UNIQUEMENT PAR DU PERSONNEL QUALIFIÉ**

Le personnel d'exploitation ne doit pas essayer de remplacer des composants ou de faire des réglages internes. Tout dépannage doit être uniquement effectué par du personnel qualifié.

### **PRÉCAUTION EN CAS D'UTILISATION AVEC DES PRODUITS DANGEREUX**

Si des produits dangereux sont utilisés, l'utilisateur est responsable de la prise des mesures de précaution appropriées, de la purge complète de l'appareil quand cela est nécessaire, et de la garantie que les produits utilisés sont compatibles avec les composants de cet appareil, y compris les matériaux d'étanchéité.

### **PURGE DE L'APPAREIL**

Après l'installation de l'unité, ou avant son enlèvement d'un système, purger l'unité complètement avec un gaz propre et sec afin d'éliminer toute trace du produit de flux utilisé précédemment.

### **UTILISATION DES PROCÉDURES APPROPRIÉES POUR LA PURGE**

Cet appareil doit être purgé sous une hotte de ventilation, et il faut porter des gants de protection.

### **PAS D'EXPLOITATION DANS UN ENVIRONNEMENT EXPLOSIF**

Pour éviter toute explosion, ne pas utiliser cet appareil dans un environnement explosif, sauf en cas d'homologation spécifique pour une telle exploitation.

### **UTILISATION D'ÉQUIPEMENTS APPROPRIÉS ET PROCÉDURES DE SERRAGE**

Tous les équipements de l'appareil doivent être cohérents avec ses spécifications, et compatibles avec l'utilisation prévue de l'appareil. Assembler et serrer les équipements conformément aux directives du fabricant.

## **VÉRIFICATION DE L'ÉTANCHÉITÉ DES CONNEXIONS**

Vérifier attentivement toutes les connexions des composants pour le vide afin de garantir l'étanchéité de l'installation.

## **EXPLOITATION AVEC DES PRESSIONS D'ENTRÉE NON DANGEREUSES**

Ne jamais utiliser des pressions supérieures à la pression nominale maximum (se reporter aux spécifications de l'unité pour la pression maximum admissible).

## **INSTALLATION D'UN DISQUE D'ÉCHAPPEMENT ADAPTÉ**

En cas d'exploitation avec une source de gaz pressurisé, installer un disque d'échappement adapté dans le système à vide, afin d'éviter une explosion du système en cas d'augmentation de la pression.

## **MAINTIEN DE L'UNITÉ À L'ABRI DES CONTAMINATIONS**

Ne pas laisser des produits contaminants pénétrer dans l'unité avant ou pendant l'utilisation. Des produits contaminants tels que des poussières et des fragments de tissu, de glace et de métal peuvent endommager l'unité d'une manière permanente ou contaminer le processus.

## **RESPECT DU TEMPS D'ÉCHAUFFEMENT APPROPRIÉ POUR LES UNITÉS À TEMPÉRATURE CONTRÔLÉE**

Les unités à température contrôlée atteignent leurs spécifications uniquement quand on leur laisse un temps suffisant pour atteindre d'une manière stable la température d'exploitation. Ne pas remettre à zéro ou calibrer l'unité tant que l'échauffement n'est pas terminé.

## Medidas de seguridad del transductor de presión

### Símbolos usados en este manual de instrucciones

Definiciones de los mensajes de advertencia, precaución y de las notas usados en el manual.

---

#### Advertencia



**El símbolo de advertencia indica la posibilidad de que se produzcan daños personales. Pone de relieve un procedimiento, práctica, estado, etc. que en caso de no realizarse u observarse correctamente puede causar daños personales.**

---

---

#### Precaución



**El símbolo de precaución indica la posibilidad de producir daños al equipo. Pone de relieve un procedimiento operativo, práctica, estado, etc. que en caso de no realizarse u observarse correctamente puede causar daños o la destrucción total o parcial del equipo.**

---

---

#### Nota



**El símbolo de notas indica información de importancia. Este símbolo pone de relieve un procedimiento, práctica o condición cuyo conocimiento es esencial destacar.**

---

## Símbolos hallados en la unidad

La tabla siguiente contiene los símbolos que puede hallar en la unidad.

<b>Definición de los símbolos hallados en la unidad</b>			
Encendido (alimentación eléctrica) IEC 417, N° 5007	Apagado (alimentación eléctrica) IEC 417, N° 5008	Puesta a tierra IEC 417, N° 5017	Protección a tierra IEC 417, N° 5019
Caja o chasis IEC 417, N° 5020	Equipotencialidad IEC 417, N° 5021	Corriente continua IEC 417, N° 5031	Corriente alterna IEC 417, N° 5032
Corriente continua y alterna IEC 417, N° 5033-a	Equipo de clase II IEC 417, N° 5172-a	Corriente alterna trifásica IEC 617-2, N° 020206	
Precaución. Consulte los documentos adjuntos ISO 3864, N° B.3.1	Precaución. Riesgo de descarga eléctrica ISO 3864, N° B.3.6	Precaución. Superficie caliente IEC 417, N° 5041	

Tabla 4: Definición de los símbolos hallados en la unidad

## **Procedimientos y precauciones de seguridad**

Las precauciones generales de seguridad descritas a continuación deben observarse durante todas las etapas de funcionamiento del instrumento. La falta de cumplimiento de dichas precauciones o de las advertencias específicas a las que se hace referencia en el manual, constituye una violación de las normas de seguridad establecidas para el uso previsto del instrumento y podría anular la protección proporcionada por el equipo. Si el cliente no cumple dichas precauciones y advertencias, MKS Instruments, Inc. no asume responsabilidad legal alguna.

### **NO UTILICE PIEZAS NO ORIGINALES O MODIFIQUE EL INSTRUMENTO**

No instale piezas que no sean originales ni modifique el instrumento sin autorización. Para asegurar el correcto funcionamiento de todos los dispositivos de seguridad, envíe el instrumento al Centro de servicio y calibración de MKS toda vez que sea necesario repararlo o efectuar tareas de mantenimiento.

### **LAS REPARACIONES DEBEN SER EFECTUADAS ÚNICAMENTE POR TÉCNICOS AUTORIZADOS**

Los operarios no deben intentar reemplazar los componentes o realizar tareas de ajuste en el interior del instrumento. Las tareas de mantenimiento o reparación deben ser realizadas únicamente por personal autorizado.

### **TENGA CUIDADO CUANDO TRABAJE CON MATERIALES TÓXICOS**

Cuando se utilicen materiales tóxicos, es responsabilidad de los operarios tomar las medidas de seguridad correspondientes, purgar totalmente el instrumento cuando sea necesario y comprobar que el material utilizado sea compatible con los materiales del instrumento e inclusive, con todos los materiales de sellado.

### **PURGUE EL INSTRUMENTO**

Una vez instalada la unidad o antes de retirarla del sistema, purge completamente la unidad con gas limpio y seco para eliminar todo resto de la sustancia líquida empleada anteriormente.

### **USE PROCEDIMIENTOS ADECUADOS PARA REALIZAR LA PURGA**

El instrumento debe purgarse debajo de una campana de ventilación y deben utilizarse guantes protectores.

### **NO HAGA FUNCIONAR EL INSTRUMENTO EN AMBIENTES CON RIESGO DE EXPLOSIÓN**

Para evitar que se produzcan explosiones, no haga funcionar este instrumento en un ambiente con riesgo de explosiones, excepto cuando el mismo haya sido certificado específicamente para tal uso.

## **USE ACCESORIOS ADECUADOS Y REALICE CORRECTAMENTE LOS PROCEDIMIENTOS DE AJUSTE**

Todos los accesorios del instrumento deben cumplir las especificaciones del mismo y ser compatibles con el uso que se debe dar al instrumento. Arme y ajuste los accesorios de acuerdo con las instrucciones del fabricante.

## **COMPRUEBE QUE LAS CONEXIONES SEAN A PRUEBA DE FUGAS**

Inspeccione cuidadosamente las conexiones de los componentes de vacío para comprobar que hayan sido instalados a prueba de fugas.

## **HAGA FUNCIONAR EL INSTRUMENTO CON PRESIONES DE ENTRADA SEGURAS**

No haga funcionar nunca el instrumento con presiones superiores a la máxima presión nominal (en las especificaciones del instrumento hallará la presión máxima permitida).

## **INSTALE UNA CÁPSULA DE SEGURIDAD ADECUADA**

Cuando el instrumento funcione con una fuente de gas presurizado, instale una cápsula de seguridad adecuada en el sistema de vacío para evitar que se produzcan explosiones cuando suba la presión del sistema.

## **MANTENGA LA UNIDAD LIBRE DE CONTAMINANTES**

No permita el ingreso de contaminantes en la unidad antes o durante su uso. Los productos contaminantes tales como polvo, suciedad, pelusa, lascas de vidrio o virutas de metal pueden dañar irreparablemente la unidad o contaminar el proceso.

## **CALIENTE ADECUADAMENTE LAS UNIDADES CONTROLADAS POR MEDIO DE TEMPERATURA**

Las unidades controladas por medio de temperatura funcionarán de acuerdo con las especificaciones sólo cuando se las caliente durante el tiempo suficiente para permitir que lleguen y se estabilicen a la temperatura de operación indicada. No calibre la unidad y no la ponga en cero hasta que finalice el procedimiento de calentamiento.

This page intentionally left blank.



# Chapter One: General Information

## Introduction

This manual describes the MKS 690A Series (Absolute) and 698A Series (Differential) Baratron® Pressure Transducers.

These transducers, when used with their required MKS Type 670<sup>1</sup> Signal Conditioner/Readout, represent the best pressure measurement system (sensor/transducer, signal conditioner, digital readout) currently produced by MKS. For further information on the companion Signal Conditioner/Readout, please refer to the 670 instruction manuals.

These precision pressure measurement systems are available with high basic accuracies, wide dynamic range, and a typical Zero Coefficient of 1 to 2 ppm/ °C and a Span Coefficient of 10 to 15 ppm/°C (higher for the 100 mTorr range).



Figure 1: Type 690A Pressure Transducer

---

<sup>1</sup>The Type 670 Signal Conditioner/Readout is required for CE mark compliance.

## **How This Manual is Organized**

This manual is designed to provide instructions on how to set up, install, and operate a Type 690A/698A unit.

**Before installing your Type 690A/698A unit in a system and/or operating it, carefully read and familiarize yourself with all precautionary notes in the *Safety Messages and Procedures* section at the front of this manual. In addition, observe and obey all WARNING and CAUTION notes provided throughout the manual.**

Chapter One, *General Information*, (this chapter) introduces the product and describes the organization of the manual.

Chapter Two, *Installation*, explains the environmental requirements and describes how to mount the instrument in your system.

Chapter Three, *Overview*, gives a brief description of the instrument and its functionality.

Chapter Four, *Operation*, describes how to use the instrument and explains all the functions and features.

Chapter Five, *Maintenance and Troubleshooting*, lists any maintenance required to keep the instrument in good working condition, and provides a checklist for reference should the instrument malfunction.

Appendix A, *Product Specifications*, lists the specifications of the instrument.

Appendix B, *Model Code Explanation*, describes the instruments ordering code.

## **Customer Support**

Standard maintenance and repair services are available at all of our regional MKS Calibration and Service Centers, listed on the back cover. In addition, MKS accepts the instruments of other manufacturers for recalibration using the Primary and Transfer Standard calibration equipment located at all of our regional service centers. Should any difficulties arise in the use of your Type 690A/698A instrument, or to obtain information about companion products MKS offers, contact any authorized MKS Calibration and Service Center. If it is necessary to return the instrument to MKS, please obtain an RMA (Return Material Authorization) Number from the MKS Calibration and Service Center before shipping. The RMA Number expedites handling and ensures proper servicing of your instrument.

Please refer to the inside of the back cover of this manual for a list of MKS Calibration and Service Centers.

---

### **Warning**



**All returns to MKS Instruments must be free of harmful, corrosive, radioactive, or toxic materials.**

---

## Chapter Two: Installation

### How To Unpack the Type 690A/698A Unit

MKS has carefully packed the Type 690A/698A unit so that it will reach you in perfect operating order. Upon receiving the unit, however, you should check for defects, cracks, broken connectors, etc., to be certain that damage has not occurred during shipment.

---

**Note**

Do *not* discard any packing materials until you have completed your inspection and are sure the unit arrived safely.

---

If you find any damage, notify your carrier and MKS immediately. If it is necessary to return the unit to MKS, obtain an RMA (Return Material Authorization) Number from the MKS Service Center before shipping. Please refer to the inside of the back cover of this manual for a list of MKS Calibration and Service Centers.

---

**Caution**

Only qualified individuals should perform the installation and any user adjustments. They must comply with all the necessary ESD and handling precautions while installing and adjusting the instrument. Proper handling is essential when working with all highly sensitive precision electronic instruments.

---

#### **Unpacking Checklist**

##### *Standard Equipment:*

- Type 690A/698A Unit
- Type 690A/698A Instruction Manual (this book)

##### *Optional Equipment:*

- Electrical Connector Accessories Kit  
690A-K1  
698A-K1
- Interface cables (refer to Table 4, page 22)
- Type HS-1 Transducer Simulator

## Interface Cables

*As of July 20, 2009, most products shipped to the European Community must comply with the EMC Directive 2004/108/EEC, which covers radio frequency emissions and immunity tests. In addition, as of January 1, 1997, some products shipped to the European Community must also comply with the Product Safety Directive 92/59/EEC and Low Voltage Directive 73/23/EEC, which cover general safety practices for design and workmanship. MKS products that meet these requirements are identified by application of the CE Mark.*

To ensure compliance with EMC Directive 2004/108/EEC, an overall metal braided shielded cable, properly grounded at both ends, is required during use. No additional installation requirements are necessary to ensure compliance with Directives 92/59/EEC and 73/23/EEC.

---

**Note**

1. Overall metal braided shielded cables, properly grounded at both ends, are required to meet CE specifications.
  2. To order metal braided shielded cables, add an "S" after the cable type designation. For example, to order a standard cable to connect the 690A transducer to a 670 unit, use part number CB270-2-10; for a metal braided shielded cable, use part number CB270S-2-10.
- 

### **System Interface Cables**

<b>System Interface Cables</b>			
<b>To Connect the 698A/698A Unit To...</b>	<b>Use the MKS Cable...</b>		
	<b>Standard</b>	<b>Shielded</b>	
670	CB270-2-10	CB270S-2-10	
	CB270-2-20	CB270S-2-20	
	CB270-2-40	CB270S-2-40	

Table 5: System Interface Cables

### Generic Shielded Cables

MKS offers a full line of cables for all MKS equipment. Should you choose to manufacture your own cables, follow the guidelines listed below:

1. The cable must have an overall metal *braided* shield, covering all wires. Neither aluminum foil nor spiral shielding will be as effective; using either may nullify regulatory compliance.
2. The connectors must have a metal case which has direct contact to the cable's shield on the whole circumference of the cable. The inductance of a flying lead or wire from the shield to the connector will seriously degrade the shield's effectiveness. The shield should be grounded to the connector before its internal wires exit.
3. With very few exceptions, the connector(s) must make good contact to the device's case (ground). "Good contact" is about 0.01 ohms; and the ground should surround all wires. Contact to ground at just one point may not suffice.
4. For shielded cables with flying leads at one or both ends; it is important at each such end, to ground the shield *before* the wires exit. Make this ground with absolute minimum length. Refer to Figures 2 and 3, page 24. (A  $\frac{1}{4}$  inch piece of #22 wire may be undesirably long since it has approximately 5 nH of inductance, equivalent to 31 ohms at 1000 MHz). After picking up the braid's ground, keep wires and braid flat against the case. With very few exceptions, grounded metal covers are not required over terminal strips. If one is required, it will be stated in the Declaration of Conformity or in the instruction manual.
5. In selecting the appropriate type and wire size for cables, consider:
  - A. The voltage ratings;
  - B. The cumulative  $I^2R$  heating of all the conductors (keep them safely cool);
  - C. The IR drop of the conductors, so that adequate power or signal voltage gets to the device;
  - D. The capacitance and inductance of cables which are handling fast signals, (such as data lines or stepper motor drive cables); and
  - E. That some cables may need internal shielding from specific wires to others; please see the instruction manual for details regarding this matter.

**Example 1: Preferred Method To Connect Cable**  
*(shown on a transducer)*




Figure 2: Preferred Method To Connect an Overall Metal Braided Shielded Cable

**Example 2: Alternate Method To Connect Cable**  
*(shown on a transducer)*




Figure 3: Alternate Method To Connect an Overall Metal Braided Shielded Cable  
*(Use this method when cable clamp is not available)*

## Setup

### Dimensions

**Note**



All dimensions are listed in inches.




Figure 4: Dimensions of Type 690A and 698A Pressure Transducers

## Mounting Instructions

The Type 690A/698A transducer must be mounted horizontally upon its vibration isolation base with the following points noted.

### Warning



**The unit *must* be mounted horizontally.**

**Do not mount the Type 690A/698A pressure transducer vertically or upside down. The vibration mount assembly is not designed to support the weight of the unit in either position.**

- A. All units are supplied with vibration isolators which should be used for maximum stability. A flexible bellows connection is suggested to minimize vibration. Furthermore, it is recommended that the sensor be mounted such that the sensor diaphragm plane is parallel to the major axis of vibration (diaphragm plane is perpendicular to port axis).
- B. Ambient temperature around the 690A/698A transducer must not rise above 40° C as this will cause the 45° to 47° C control temperature to go out of regulation, thus destroying the system stability.
- C. Mount the transducer as far from RFI and EMI sources as possible. Field experience has shown that care in positioning the transducer initially will prevent future difficulties. The MKS system is internally protected against RFI and EMI. However, in a system where several ground potentials are possible, a noisy environment may cause output to be unstable. When this happens, we have found the only solution has been an examination and correction of the source of RFI/EMI.

*Example:*

An SCR supply used in some systems should have the power-carrying wires that run to the chamber twisted to cancel high frequency magnetic fields. Never run the 690A transducer to Signal Conditioner cable in the same wiring bundle as RF or SCR signals.

- D. The system interface cables are listed in Table 4, page 22.
- E. *The vibration mount assembly is shipped from MKS with two shipping screws in place.* For noise-free operation, these screws must be removed. However, when this Baratron is subsequently reshipped on a piece of equipment, these screws **must be reinstalled** as the rubber feet will withstand no more than 3 g's force in transit.
- F. When installing a 698A differential transducer, allow for a cross-porting manifold; that is, connecting the two ports together. In order to properly set the zero of any differential sensor, there must be equal pressure on both sides of the sensor.

G. Vacuum Connections: The sensor should be connected to the vacuum system via an appropriate isolation valve and bellows tubing.

- a. To maximize the life and zero repeatability of the sensor, an isolation valve should be used. Set its closing point at or slightly above the transducer's full scale range.

An isolation valve serves to protect the sensor in two ways:

First: From overpressure in excess of the sensor's specifications, which is common in processing systems.

690A Absolute: 125% of FS or 45 psia (whichever is greater)

698A Differential: 125% of FS or 45 psia (whichever is greater)  
(lower for 100 mTorr Range)

Second: From contamination by moisture, which is present when a process system is vented to atmosphere. Moisture can often combine with residue on the sensor and/or system surfaces, and form acids such as HCl when chlorine - based processes are used.

Any high-quality electric, or air-operated valve, can be used for isolation.

- b. The sensor inlet should be connected to the isolation valve via an appropriate length of stainless steel bellows tubing with welded mating fittings. Both VCR fittings and flexible tubing are products of the Swagelok Company.

The use of a flexible bellows completes vibration isolation to the sensor, allowing it to function independently of significant system vibration or stress that could be induced during operation or shipment.

---

**Caution**

**Hard coupling of the sensor inlet tube so that the transducer is suspended by this tube is not recommended as the weight of the entire assembly will cause stress on the sensor.**

---

- c. 698A Differential Sensors: The  $P_X$  port must be connected to the high side of any system whose differential pressure is to be measured. The  $P_R$  side will then be connected to the low pressure side. If connections are reversed, the instrument will output a negative signal whose accuracy is not specified. A 698A differential sensor may be used to make an absolute measurement, by continually pumping the  $P_R$  port to a pressure below that of the resolution of the sensor. (Example: 1mm Hg FS  $\times 10^{-6} = <10^{-6}$  mm Hg).

**Caution**

---

**Do not attempt to change the inlet tube fitting by cutting or welding. If a different fitting is desired, make up an adaptor, or consult MKS for a quotation on a special-version sensor.**

---

For your convenience, MKS makes available several lengths of these bellows assemblies, including the mating VCR fittings welded to the bellows tubing. To order, specify P/N 6BL 4VCR for a 6" length, or P/N 12BL 4VCR for a 12" length.

## Chapter Three: Overview

### Functional Description

The 690A/698A Baratron is composed of four (4) sub-sections assembled within a precision die-cast housing. These are: 1) an Inconel® variable capacitance diaphragm sensor; 2) an electronic preamplifier and bridge circuits; 3) an inner temperature control housing; 4) a PC Board. The all-Inconel sensor, together with its high impedance bridge circuit and preamp, is mounted within a thick-walled, temperature controlled aluminum housing. This miniature “environmental chamber” reduces the ambient temperature effects upon the sensor and bridge circuit by more than a factor of 50.

The main PC board mounted outside the temperature-controlled housing consists of those circuits necessary to convert a low level 10 KHz signal to a precise  $\frac{1}{4}$  V/V output that is linearly proportional to pressure. Also, that circuit necessary to maintain the housing temperature is located on this board. All gain-controlling components are selected for maximum stability (wire-wound resistor, NPO capacitor, etc.). A “system check” circuit is used which will point out any gain change experienced at any point in the electrical system.

The 690A Baratron is able to make a reliable absolute pressure measurement by virtue of its own built-in “zero” pressure reference cavity. During production, the low pressure side ( $P_R$ ) of the sensor is pumped to less than  $1 \times 10^{-7}$  Torr, outgassed thoroughly, chemically gettered, and permanently sealed. The extremely low gas loads and active gettering material in the reference cavity assure the user of many years of useful service.

The 698A Baratron is unique, in that the entire differential sensor is surrounded by an Inconel case. Ambient line pressure ( $P_R$ ) appears between the sensor and this case, thus eliminating sensitivity changes due to line pressure induced stress variations within the sensor structure. Careful deadweight testing has shown a variation of less than 0.01% of reading as the line pressure varies from 1 to 15 psia.

## **Transducer Simulator**

The Type HS-1 Transducer Simulator is used as a test box for checkout and set-up of a precision pressure measurement system (690A/698A, and 670 signal conditioner). The simulator provides the following functions:

1. A dummy load for, and LED visual signal of, the heater supply power.
2. A visual signal of the  $\pm 15$  VDC power supply function.
3. The generation of a zero, 50% FS, and 100% FS signal.
4. Test points for the measurement of the 6 VRMS excitation signal.

Through its use, one may accomplish the following:

1. Identify a faulty transducer.
2. Identify a faulty cable.
3. Check some of the fundamental functions of the signal conditioner/readout unit.
4. Adjust for transducer-to-signal conditioner cable length.

## Chapter Four: Operation

### General Information

**Note**

It is important to remember that all diaphragm-variable capacitance pressure transducers require you to set “zero” with the signal conditioner, after suitable warm-up and pumping have been accomplished.

The following procedure is presented as an optimum guide to achieving the full design potential of the precision 690A/698A pressure measurement system.

1. (690A, 698A): After the sensor has been installed on the system whose pressure is to be measured, it should be connected to its Electronics Unit via the appropriate cable (refer to *Interface Cables*, page 22), and power applied.
2. (690A, 698A): A minimum of four (4) hours, and preferably overnight, should be allowed for the heater in the sensor package to thermally stabilize the sensor at control temperature.
3. (690A): While waiting for the sensor to reach stable thermal equilibrium, the appropriate vacuum pump(s) in the Processing System should be engaged, so as to pump down the sensor below its minimum usable resolution.  
(698A): While waiting for the sensor to reach stable thermal equilibrium, the appropriate vacuum pump(s) in the Processing System should be engaged, in such manner as to provide equal pressure on both sides of the sensor. (This can also be accomplished by cross-porting; that is, connecting the two ports together).
4. (690A, 698A): After the above warm-up time and pumping requirements have been met, the zero can be properly set.

Each full scale range has different pumping criteria. The following chart summarizes the basic pressures needed prior to setting the Zero.

<b>Maximum Pressures For Proper Zero Adjustment</b>			
<b>Sensor Model Number</b>	<b>Range Full Scale</b>	<b>Highest Pressure for Proper Zero Adjust</b>	<b>Warm-Up Time Before Adjusting Zero</b>
690A.1Txx	100 mTorr	$< 1 \times 10^{-7}$ Torr	4 Hours Minimum*
690A01Txx	1 Torr	$< 1 \times 10^{-6}$ Torr	"
690A11Txx	10 Torr	$< 1 \times 10^{-5}$ Torr	"
690A12Txx	100 Torr	$< 1 \times 10^{-4}$ Torr	"
690A13Txx	1000 Torr	$< 1 \times 10^{-3}$ Torr	"
698A14Txx	10000 Torr	$< 1 \times 10^{-2}$ Torr	"

*\* It is recommended that all temp-controlled transducers be powered continuously.*

Table 6: Maximum Pressures for Proper Zero Adjustment

## **How To Zero the Transducer**

### **How To Zero the Transducer Using the Zero Pot**

The best method of zeroing the transducer system is:

1. Center the fine pot in the Electronics Unit.

This is accomplished by turning the pot to either extreme, noting the voltages at each extreme, and then setting the pot at the half way point.

2. Adjust the zero using the coarse zero pot on the electronics unit.

---

**Note**

The sensor zero pot is factory set during calibration, and should **never** be adjusted by the user unless there are suitable transfer or primary standards available to aid in recalibration.

---

3. Fine-trim the output, using the zero controls on the Electronics Unit.

The measurement system is now ready to use.

For reference, the frequency of setting the zero will depend on use, variations in ambient temperature, and your application. You will, with experience, gain a feeling for the frequency with which the zero adjustment must be made. For extremely critical measurement of very low pressures, checking the zero more often and making minor adjustments will ensure the most accurate measurements attainable with this MKS Baratron transducer system.

---

**Note**

1. The span of the sensor is factory set during the calibration, and should **never** be adjusted by the user unless there are suitable transfer or primary standards available to aid in recalibration.
  2. If the Zero or Span potentiometers in the sensor head preamplifier are mistakenly adjusted, please contact your nearest MKS Service Center for assistance, and possible instructions to return the instrument to MKS for recalibration.
- 

A 0.1 Torr 690A or 698A transducer operates within specifications if the range of the signal conditioner is set to either X1 or X.1. A 0.1 Torr 690A/698A transducer **should not** be set to the X.01 range. Operation of a 0.1 Torr transducer in the X.01 signal conditioner range may create electrical noise to the point of excessively distorting the pressure signal which, in turn, causes both linearity and zero errors.

If use of the Sensor Zero Coarse and Fine controls on the signal conditioner does not provide enough range, zero adjustment of a 0.1 Torr 690A or 698A transducer can be performed using the Zero control on the transducer. The Zero control is located at the top of the transducer within the lower loop of the letter B (in the word *Baratron*).

## How To Zero The Transducer using the Zero Control

To zero a 0.1 Torr 690A/698A transducer using the Zero control:

1. Pump the transducer down, with the heater on, to less than  $5 \times 10^{-7}$  Torr and let it stabilize for a minimum of 16 hours.
2. Center both the Sensor Zero Coarse and Fine controls on the signal conditioner by first turning the controls completely counter-clockwise and then turning them 15 complete turns clockwise.
3. Follow the instructions below and adjust the Zero control on the 690A/698A unit until the output displayed on the signal conditioner reads nearly zero.
  - a. The Zero control on the 690A/698A transducer is a wire-wound potentiometer with approximately 100 turns or positions (wires). It is essentially a 100-position switch with 200 to 1000 ppm FS per position.
  - b. The stability of the setting is maintained if the Zero control shaft is adjusted to center the wiper on an individual wire. If the wiper is not well centered on the wire, it may move either with time or due to vibration or temperature changes and cause large shifts in the zero.
  - c. Locating the center of a wire is complicated by the variable backlash between the zero control shaft and the wiper. Therefore, MKS does **not recommend** using the technique of turning the pot to either extreme, noting the voltage at each end, and positioning the pot midway.

## How To Properly Adjust the Zero Control

To properly adjust the Zero control on a 0.1 Torr 690A/698A transducer:

1. Verify that there are four distinct and stable steps for each revolution of the Zero control shaft as evidenced by the output displayed on the signal conditioner.

A step is considered to be stable if the output does not change while the shaft is turned  $\frac{1}{8}$  of a turn further in the same direction.

2. Turn the Zero control in either direction to adjust it to the *stable* step nearest zero, and record the output displayed on the signal conditioner.

It is generally not possible to achieve a precise zero due to the resolution of this control. Turn the Zero control an extra  $\frac{1}{2}$  turn in the *same* direction.

3. Turn the zero control back slowly in the *opposite* direction until the output first achieved in step 5 occurs. Then, carefully turn the Zero control an additional  $\frac{1}{8}$  turn in this *same* direction.

Performing this last  $\frac{1}{8}$  turn centers the pot in the middle of a step to achieve maximum stability.

4. Use both the sensor Zero Coarse and Fine controls on the signal conditioner to adjust the output displayed to precisely zero.

When using the Fine control, it may be necessary to adjust the range of the signal conditioner to X.1 (do not use X.01) for the final setting.

## **How To Perform a System Check**

The System Check circuit generates a span calibration signal whose precision depends upon the position of the head's zero pot.

To perform a system check:

1. Disconnect the head cable from the transducer and connect it to the HS-1 simulator.  
The red lamp should be ON, indicating that the proper preamp voltage is present at the end of the cable.
2. Place the switch in the zero position.  
A zero signal is developed across the signal input lines. In this position it should be possible to adjust the electronics unit for a stable zero on all ranges.
3. Place the switch in the +10 V position.  
The simulator will produce a signal sufficient to produce a stable +10 V (full scale) reading on the X1 range.

The HS-1 simulator also contains a resistor to simulate the heater in the sensor. When the heater switch is placed in the REG. position, the heater lamps on the electronics unit will come ON if the supply is working properly. This lamp will not display the same brilliance as it does when attached to a heater due to the higher value of the simulator resistor.

## **How To Recalibrate the Electronics Unit**

1. Connect a high accuracy AC meter to the jacks on the top of the simulator and measure the amplitude of the oscillator.  
The proper level is 6.000 VRMS.
2. Place the simulator switch in the zero position.
3. Adjust the Null and Full Scale on the indicator and then the zero on all ranges.
4. Place the range multiplier in the X1 position and the simulator switch in the +10 V position.
5. Adjust the full scale pot on the front of the electronics unit for a reading of +10.00 Volts at the output of the electronics unit.
6. Place the simulator switch in the +5 V position to check linearity at the 50% point.  
This should be within 5 mV of 5.00 Volts.



## **How To Optimize Long Cable Operation**

When long transducer cables are used in a system, frequently it is necessary to adjust the system gain to optimize system performance which might be degraded due to the cable length. When the simulator is installed on the end of the transducer cable, the system gain is adjusted by using the procedures described in *How To Perform a System Check*, and *How To Recalibrate the Electronics Unit*, page 36. Note that on occasion, the Electronics Unit span adjust may have to be adjusted if the full scale adjustment is insufficient to set full scale.

This page intentionally left blank



## **Chapter Five: Maintenance and Troubleshooting**

### **General Information**

If the 690A/698A instrument fails to operate properly upon receipt, check for shipping damages, and check the cables for continuity. Any damage should be reported to the carrier and MKS Instruments immediately. If it is necessary to return the unit to MKS, obtain an ERA number (Equipment Return Authorization Number) from a MKS Service Center before shipping. Please refer to the inside back cover of this manual for a list of MKS Calibration and Service Centers.

### **Maintenance**

Periodically check for wear on the cables and inspect the enclosure for visible signs of damage. Generally, nothing needs to be done to maintain the transducer, other than its proper installation and operation.

#### **How To Clean the Unit**

Periodically wipe down the unit with a damp cloth.

## **Troubleshooting**

After extended use, the following situations may occur:

1. Measurement goes slowly negative with time.

A reference leak may cause the zero adjustment to run out. This requires a new sensor replacement.

2. Measurement goes slowly positive with time.

Overpressure, and/or a build-up of contamination in the  $P_x$  cavity will push the diaphragm toward the electrode, causing the zero adjustment to run out. Generally, this requires a new sensor replacement.

3. OVERRANGE positive, or negative, signal.

This is generally caused by a shorted sensor, or a damaged interconnect cable (sensor to electronics module).

---

**Note**

If the “zero” output from the transducer is unstable, this is usually caused by the ambient temperature around the sensor or electronics module being too high. The ambient temperature around the sensor must be no higher than 40° C. The ambient temperature around the electronics unit must not exceed 50 °C.

---

Troubleshooting Chart		
Symptom	Cause	Remedy
CANNOT ZERO <ul style="list-style-type: none"> <li>a. With absolute head</li> <li>b. When power first applied</li> <li>c. On most sensitive ranges</li> </ul>	Pressure not below the reading resolution Head not at operating temperature Amplifier overload or system noise	Pump down $P_X$ side Allow time for stabilization (4 hours minimum) Go back to less sensitive range until on scale and try again and/or try better vibration isolation.
ZERO SHIFT <ul style="list-style-type: none"> <li>a. After applying power</li> <li>b. When changing from atmospheric to vacuum operation</li> <li>c. When either raising or lowering line</li> <li>d. Upon turn on of RF power in, for example, a sputtering system. Sudden “negative direction” pressure reading.</li> </ul>	Sensor temperature shift Different outgassing rates from $P_X$ and $P_R$ at vacuum Leaks in vacuum system Pick up in sensor preamplifier	Allow 4 to 6 hours for sensor stabilization (16 hours for optimum stability). Allow time for outgassing completion Check pressure connections at head and other fittings Replace standard sensor head cable with shielded version or relocate sensor on system or try better grounding
SYSTEM CHECK <ul style="list-style-type: none"> <li>a. System check voltage different</li> </ul>	Electronics gain has changed	Check calibration of transducer

Table 7: Troubleshooting Chart

This page intentionally left blank.

## Appendix A: Product Specifications

Ambient Operating Temperature	15° to 40° C (59° to 104° F)
Accuracy	
690A	0.12% of reading ±zero/span coeff.
Standard	
Optional	0.08% of reading ±zero/span coeff.
All ranges	
1, 10, 100, and 1000 Torr units only	0.05% of reading ±zero/span coeff.
698A	0.12% of reading ±zero/span coeff.
Standard	
Optional	0.08% of reading ±zero/span coeff.
All ranges	
1, 10, 100, and 1000 Torr units only	0.15% of reading ±zero/span coeff. 0.2% of reading ±zero/span coeff. 0.05 of reading ±zero/span coeff.
CE Mark Compliance <sup>2</sup>	EMC Directive 2004/108/EEC
Full Scale Pressure Ranges (Torr)	
690A	0.1, 1, 10, 100, 1K, 5K, 10K, 15K, 20K, 25K
698A	0.1, 1, 10, 100, 1K Torr
Inlet Tube Fitting(s)	Swagelok® 4-VCR® (female)
Line Pressure Effects on Span	
690A	N/A
698A	<0.010% / 15 psi <sup>3</sup>
Maximum Line Pressure	
690A	N/A
698A	150 psig
Measurement Side (P <sub>x</sub> ) Media Compatibility	Any gas compatible with Inconel®, 304 SS

<sup>2</sup>An overall metal braided shielded cable, properly grounded at both ends, is required during use. The Type 690A/698A units are only CE compliant when used with the Type 670 Signal Conditioner/Readout.

<sup>3</sup>For 100 mTorr units only.

P <sub>X</sub> Overpressure	
100 mTorr (0.1 T) Units	125% FS or 40 psia (whichever is greater)
All other ranges	125% FS or 45 psia (whichever is greater)
Reference Side (P <sub>R</sub> ) Media Compatibility	
690A	N/A
698A	Any dry gas compatible with Inconel®, 304/306 SS, Fosterite, Palladium
Reference Side Volume	
690A	N/A
698A	25 cc
Resolution (of FS)	1 x 10 <sup>-6</sup>
Sensor Temperature	Regulated at 45° C
Sensor Type	Single sided, dual electrode
Temperature Effects on Span	
100 mTorr (0.1 T) Units	<0.010% R / °C (100 ppm)
All other ranges	<0.002% R / °C (20 ppm)
Temperature Effects on Zero	
100 mTorr (0.1 T) Units	<30 PPM, F.S./ °C
All other ranges	
at 0.05% or 0.08% of Rdg accuracy	<4 PPM, F.S./ °C
at 0.12% of Rdg accuracy	<15 PPM, F.S./ °C
Time Constant with Signal Conditioner in:	
Fast Position	> 25 ms
Std Position	40 ms
Slow Position	400 ms
Type of Measurement	
690A	Absolute
698A	Differential, Gage
Useable Resolution	5 decades
Volume (P <sub>X</sub> )	
690A	
≥ 1000 T Units	2.5 cc
5K to 25 K Units	14 cc
698A	3.5 cc

Due to continuing research and development activities, these product specifications are subject to change without notice.

## Appendix B: Model Code Explanation


### **Model Code**

The options for your transducer are identified in the model code when you order the unit.

The model code is identified as follows:

**##### XXX Y Z**

where:



#### **Type Number (#####)**

The type number – 690A or 698A – designates the model number of the instrument.

**Full Scale Range (XXX)**

The full scale range is indicated by a two digit / one letter code.

<b>Full Scale Range in mmHg (Torr)</b>	<b>Ordering Code</b>
0.1	0.1T
1	01T
10	11T
100	12T
1,000	13T
5,000*	53T
10,000*	14T
15,000*	RBT
20,000*	24T
25,000*	RCT

\*Available with 690A unit only.

**Fittings (YY)**

One type of fitting is available, designated by a single letter code.

<b>Fittings</b>	<b>Ordering Code</b>
Swagelok 4-VCR female	R

**Accuracy (Z)**

The accuracy is designated by a single letter code.

<b>Accuracy</b>	<b>Ordering Code</b>
<i>Unidirectional Calibration (690A and 698A)</i>	
Standard: $\pm 0.12\%$ of Reading	C
Optional: $\pm 0.08\%$ of Reading	B
Optional: $\pm 0.05\%$ of Reading*	A
<i>Bidirectional Calibration (698A only)</i>	
Standard: $\pm 0.25\%$ of Reading*	E
Optional: $\pm 0.15\%$ of Reading*	D

\*Available in 1, 10, 100, and 1000 mmHg ranges only.

# Index

## A

Accuracy, 43, 46

## C

Cables

- CE mark, 22
- generic shielded, 23
- system interface, 22

CE mark, 22

Customer support, 20

## D

Dimensions, 25

## E

Electronics unit, 36

## F

Fittings, 46

Full scale range, 43, 46

## L

Long cable operation, 37

## M

Maintenance, 39

Manual organization, 20

Model code, 45

Mounting instructions, 26

## O

Operation, 31

electronics unit, 36

long cable, 37

system check, 36

## R

Returning the product, 20, 21

## S

Safety information, 1–16

Setup

dimensions, 25

mounting instructions, 26

vacuum connections, 27

Specifications, 43–44

System check, 36

## T

Transducer simulator, 30

## Z

Zero adjustment

maximum pressures, 32

zero control, 34

zero pot, 33